


Electronic trip relay(Feature)



OCR alarm (AL) (standard)

When it happen to trip by over current, ground fault (GFR) and Earth leakage (ER), it issue a warning alarm.

Neutral pole overcurrent protection (NP) (standard)

When harmonics in load current are large, the current on neutral pole exceeding rated current may flow. Harmonics may cause some troubles. Neutral pole overcurrent protection prevents them by operating at 100% of rated current on neutral pole.

MCR:Making current release (option)

Just under the breaker closing operation (from open to close), Instantaneous characteristic become effective, but after closing the breaker, instantaneous characteristic become ineffective.

When you order the MCR switch, MCR switch is built in the main body.

If MCR switch is built in the main body and the adjust dial of INST/MCR on main setting module is set the MCR position, MCR function become effective.

TAL (option)

When the temperature of main contacts exceed normal temperature level, temperature alarm is indicated at LED (on main setting module) and output by contact (only installed power supply with output contact).

If TAL is installed in the breaker according your order, Temperature alarm (LED) function become effective.

When the temperature goes down within normal templer level, the temperature alarm will be reset.

NCT (option)

Neutral CT is required for Ground fault or Neutral pole protection, when 3 pole breaker is used for 3 phase 4 wires system.

ZCT (option)

ZCT is required for a few amperes earth leakage protection, and is combining ER plug. (see page 28)

Characteristic table

① \ ②	NA Nothing	G1 Ground fault	E1 Earth leakage	AP 2nd additional Pre-alarm	N5 Neutral pole 50% protection
WS General use LTD+STD+ INST/MCR					
WM Generator protection use LTD+STD+ INST/MCR					
WB Special use INST/MCR					

Power supply module ③

Type	Rating	alarm output
P1	100-240V AC·DC	Nothing
P2	24-60V DC	Nothing
P3	100-240V AC 100-125V DC	6 output contacts
P4	24-60V DC	6 output contacts
P5	100-240V DC	6 output contacts (SSR)

Contact capacity(Type code P3, P4)

Voltage(V)		Current (A)	
		Resistive load	Inductive load
		cosφ=1.0	cosφ=0.4 L/R=7ms
AC	240	1	0.5
	120	1	1
DC	125	0.1	0.05
	30	1	1

Note1: Over current protection and ground fault protection operates without control power source.

Note2: Factory setting of 6 output contacts is as follows.

① LTD	② STD/INST	③ G1/E1/AP	④ PAL	⑤ TAL	⑥ ERR
Self-holding	Self-holding	Refer to lower table	Automatic reset	Automatic reset	Automatic reset
<div>Self-holding: The output is maintained. Automatic reset: The output will be reset to normal condition.</div>					
ETR dial set	G1	E1	AP		
TRIP side	Self-holding	Self-holding	—		
ALARM side	Automatic reset	Automatic reset	Automatic reset		

Self-holding:
The output is maintained until it resets.
Automatic reset:
The output will be reset if it backs to normal condition.

Current capacity(Type code P5)

Voltage(V)		Normal current	Peak inrush current	ON resistance (max.)
AC	240	0.1A	0.3A	5Ω
	120	0.1A	0.3A	5Ω
DC	240	0.1A	0.3A	5Ω
	30	0.1A	0.3A	5Ω

CT rating table

AE630-SW 630A	AE1000-SW 1000A	AE1250-SW 1250A	AE1600-SW 1600A	AE2000-SWA 2000A
250A	315A	500A	1250A	1600A
			AE2000-SW 2000A	AE2500-SW 2500A
				AE3200-SW 3200A
				AE4000-SWA 4000A
				AE4000-SW 4000A
				AE5000-SW 5000A
				AE6300-SW 6300A

Note1: AE630-SW and AE2000-SW has low rating type.

Please refer to the "Ordering information sheet." (Page 57-59)

Note2: Low rating type of AE630-SW is not available for the ground fault protection.

Note3: As for details of ratings, refer to page 9 and page 10.

Electronic trip relay(ETR) type code


Main setting module			Optional setting module		Power supply		Additional function		Network	
WS1, WB1, WM1	AE630-1600-SW, AE2000-3200-SW, AE4000-SW		G1: Ground fault protection		P1: AC-DC100-240V		<input type="checkbox"/> Extension module(EX1)		<input type="checkbox"/> BIF-CC	
WS2, WB2, WM2	AE2000-SWA, AE4000-SWA, AE5000-SW		N5: Neutral pole 50% protection		P2: DC24-60V		<input type="checkbox"/> Display(DP1)		<input type="checkbox"/> BIF-PR	
WS3, WB3, WM3	AE6300-SW		E1: Earth leakage protection		P3: AC100-240V / DC100-125V with output contact		<input type="checkbox"/> Display onto panel board(DP2)		<input type="checkbox"/> BIF-MD	
			AP: 2nd Additional Pre-alarm		P4: DC24-60V with output contact		<input type="checkbox"/> VT unit(VT)			
			NA: Without optional setting		P5: DC100-240V with output contact (SSR)		<input type="checkbox"/> Temperature alarm(TAL)			
							<input type="checkbox"/> MCR switch(MCR-SW)			

WS : General use

WM : Generator protection use

WB : INST/MCR only


Electronic trip relay (for general use : WS)



- A** Trip indicator LED
- B** Pre-alarm LED
- C** Temperature alarm LED
- D** Load current LED
- E** RUN LED
- F** ERR. LED
- G** Current setting dial
- H** Uninterrupted current setting dial
- I** LTD time setting dial
- J** STD pick-up setting dial
- K** STD time setting dial
- L** INST/MCR pick-up current setting dial
- M** Optional setting module (P.27~29)
- N** Pre-alarm current setting dial
- O** RESET button (TEST L/S LOCK button)
- P** TEST terminal

Note: The figure shown WS type with G1 plug.
G1 is option.

Relation of setting dial




Adjustable setting range

No.	Setting item	Mark	Adjustable setting range	Accuracy	Factory default value
G	Current setting	I _r	0.5 ~ 1.0 (0.05step) x I _n (CT rating)	—	1.0
H	Uninterrupted current	I _u	0.8 ~ 1.0 x I _r (0.02step), Pick-up current : 1.15 x I _u	1.05 x I _u ...Non Pick-up 1.25 x I _u ...Pick-up	1.0
I	LTD time	T _L	12-25-50-100-150s at I _u x 2	± 20%	150
J	STD pick-up current	I _{sd}	1.5-2-2.5-3-4-5-6-7-8-9-10 x I _r	± 15%	10
K	STD time	T _{sd}	0.5-0.4-0.3-0.2-0.1-0.06-0.06-0.1-0.2-0.3-0.4-0.5s (I _{sd} ON) (I _{sd} OFF) at I _{sd} x 1.5	± 20% It operates in the range between 0.04 and 0.08s when the time set at 0.06s.	0.5 (I _{sd} ON)
L	INST/MCR pick-up current	I _{li}	AE630-SW~AE1600-SW AE2000-SW~AE3200-SW AE4000-SW 16-12-10-8-6-4-2-2-4-6-8-10-12-16 x I _r (INST) (MCR) WS1	± 15%	WS1...16 (INST)
			AE2000-SWA, AE4000-SWA AE5000-SW 12-10-8-6-4-2-2-4-6-8-10-12 x I _r (INST) (MCR) WS2		WS2...12 (INST)
			AE6300-SW 10-8-6-4-2-2-4-6-8-10 x I _r (INST) (MCR) WS3		WS3...10 (INST)
N	Pre-alarm current	I _p	I _u x 0.68 ~ 1.0 (0.04step) -OVER	± 10%	OVER
—	Pre-alarm time	T _p	1/2 T _L at I _u x 2 (after 1/2 T _L , PAL contact output turns on.)	± 20%	—

Upper figure and table denote the case optional MCR function is included.


Electronic trip relay(for generator protection use:WM)



- A** Trip indicator LED
- B** Pre-alarm LED
- C** Temperature alarm LED
- D** Load current LED
- E** RUN LED
- F** ERR. LED
- G** LTD pick-up current
- H** LTD time setting dial
- I** STD pick-up setting dial
- J** STD time setting dial
- K** INST/MCR pick-up current setting dial
- L** Optional setting module (P.27~29)
- M** Pre-alarm current setting dial
- N** RESET button (TEST L/S LOCK button)
- O** TEST terminal

Note: The figure shown WM1 type with G1 plug and Display (DP1).
G1 and DP1 are options.

Relation of setting dial




Adjustable setting range


No.	Setting item	Mark	Adjustable setting range	Accuracy	Factory default value
—	Current setting	Ir	0.63 ~ 1.0 x In (Adjust by factory : Fixed)	—	Comply with ordering sheet
G	LTD pick-up current	IL	1.0—1.05—1.1— 1.15 —1.2 x Ir	± 5%	1.15
H	LTD time	T _L	15— 20 —25—30—40—60s at IL x 1.2	± 20%	20
I	STD pick-up current	I _{sd}	1.5—2—2.5—3—3.5—4—4.5— 5 x Ir	± 15%	5
J	STD time	T _{sd}	0.5 —0.4—0.3—0.2—0.1—0.06— 0.06 —0.1—0.2—0.3—0.4—0.5s (I _{1t} ON) (I _{1t} OFF) at I _{sd} x 1.5	± 20% It operates in the range between 0.04 and 0.08s when the time set at 0.06s.	0.5 (I _{1t} ON)
K	INST/MCR pick-up current	I _i	AE630-SW~AE1600-SW AE2000-SW~AE3200-SW 16 -12-10-8-6-4-2-2-4-6-8-10-12-16 x Ir (INST) (MCR) WM1	± 15%	WM1...16 (INST)
			AE2000-SWA, AE4000-SWA 12 -10-8-6-4-2-2-4-6-8-10-12 x Ir AE5000-SW (INST) (MCR) WM2		WM2...12 (INST)
			AE6300-SW 10 -8-6-4-2-2-4-6-8-10 x Ir (INST) (MCR) WM3		WM3...10 (INST)
M	Pre-alarm current	I _p	I _L x 0.68 ~ 1.0 (0.04step) — OVER	± 5%	OVER
—	Pre-alarm time	T _p	1/2 T _L at I _L x 1.2 (after 1/2 T _L , PAL contact output turns on.)	± 20%	—

Upper figure and table denote the case optional MCR function is included.
Pre-alarm current "OVER" setting is equal to 1.0.

■ Operating characteristic curve (for generator protection use : WM)




Electronic trip relay(for special use : WB)



- A Trip indicator LED
- B Pre-alarm LED
- C Temperature alarm LED
- D Load current LED
- E RUN LED
- F ERR. LED
- G Current setting dial
- H INST/MCR pick-up current setting dial
- I Pre-alarm current setting dial
- J RESET button
- K TEST terminal

Relation of setting dial




Adjustable setting range

No.	Setting item	Mark	Adjustable setting range	Accuracy	Factory default value
G	Current setting	Ir	0.5 ~ 1.0 (0.05step) x In (CT rating)	—	1.0
H	INST/MCR pick-up current	li	<div>AE630-SW~AE1600-SW AE2000-SW~AE3200-SW AE4000-SW</div> <div>$\frac{16-12-10-8-6-4-2-2-4-6-8-10-12-16}{(INST) \quad (MCR)} \times Ir$ WB1</div> <div>AE2000-SWA, AE4000-SWA AE5000-SW</div> <div>$\frac{12-10-8-6-4-2-2-4-6-8-10-12}{(INST) \quad (MCR)} \times Ir$ WB2</div> <div>AE6300-SW</div> <div>$\frac{10-8-6-4-2-2-4-6-8-10}{(INST) \quad (MCR)} \times Ir$ WB3</div>	± 15%	<div>WB1...16 (INST)</div> <div>WB2...12 (INST)</div> <div>WB3...10 (INST)</div>
I	Pre-alarm current	Ip	Ir x 0.68 ~ 1.0 (0.04step) —OVER	± 10%	OVER
—	Pre-alarm time	Tp	75s at Ir x 2 (after 75s, PAL contact output turns on.)	± 20%	—

Upper figure and table denote the case optional MCR function is included.

■ Operating characteristic curve (for special use : WB)



Electronic trip relay

Accessories

Ground fault protection(GFR)

Option



The ground fault protection (GFR) of several hundred amperes is possible. This function can be selected for trip and alarm (no trip). Power supply is necessary for this function, even if there is not power supply, it can function at $0.2 \times I_n$ or higher.

Setting item	Mark	Adjustable setting range	Accuracy	Factory default value
GFR pick-up current	Ig	0.1-0.2-0.3-0.4-0.5-0.6-0.7-0.8-0.9-1.0 $\times I_n$	$\pm 20\%$	1.0
GFR time	Tg	<div> <div> 3-1.5-0.8-0.5-0.3-0.15-<0.1 </div> <div> 0.1-0.15-0.3-0.5-0.8-1.5-3s </div> </div> <div> <div>TRIP</div> <div>ALARM (at $1.5 \times I_g$)</div> </div>	$\pm 20\%$	3s (TRIP)
alarm output	—	TRIP side : Self-holding/ALARM side : Automatic reset	—	TRIP side (Self-holding)


Neutral CT(NCT) ※Only use for AE-SW

Option




The Neutral CT is used for ground fault protection when the 3 pole breaker is used on a 3 phase 4 wires system and for over current protection on N phase. Please use this CT in combination with ground fault protection (GFR). As for outline dimensions, refer to page 50.
The length of the cable (attached) for NCT is 2m.

GFR function block diagram (In case of 4pole breaker)



Block diagram with NCT function




NCT type name

ACB type name / CT rating		Applicable NCT type name
AE630-SW 630A		NCT06
AE1000-SW 1000A		NCT10
AE1250-SW 1250A	AE2000-SW 1250A	NCT12
AE1600-SW 1600A	AE2000-SW 1600A	NCT16
AE2000-SWA 2000A	AE2000-SW 2000A	NCT20
	AE2500-SW 2500A	NCT25
	AE3200-SW 3200A	NCT32
	AE4000-SWA 4000A	NCT40

As for outline dimensional drawing, refer to page 50.

Ground fault protection characteristics



Earth leakage protection(ER)

Option




By combining the ETR with earth leakage protection (ER) and External ZCT, earth leakage protection is possible. Earth leakage protection, earth leakage tripping and earth leakage alarm can be selected. Control supply is necessary for this function.

Setting item	Mark	Adjustable setting range	Accuracy	Factory default value
ER pick-up current	$I_{\Delta n}$	1A-2A-3A-5A-10A	+0% -30%	10A
ER time	T_e	<div> <div>TRIP</div> <div>ALARM</div> </div> <div> <div>3-1.5-0.8-0.5-0.3-0.15-<0.1</div> <div>-<0.1-0.15-0.3-0.5-0.8-1.5-3s</div> </div> <div> <div></div> <div>(at 1.5 x $I_{\Delta n}$)</div> </div>	$\pm 20\%$	3s (TRIP)
alarm output	—	TRIP side : Self-holding/ALARM side : Automatic reset	—	TRIP side (Self-holding)

External ZCT

Option



This option is used to detect several amperes of earth leakage when use in combination with a electronic trip relay that has the earth leakage tripping (ER) option.
Two methods are available. The first is where the all load conductors pass through the ZCT. The other method uses a smaller ZCT through which the supply transformer's ground wire passes through to earth.

ZCT for load circuit


ZCT type name	ACB type name
ZCT163	AE630-SW ~ AE1600-SW 3-pole
ZCT323	AE630-SW ~ AE1600-SW 4-pole
ZCT324	AE2000-SW ~ AE3200-SW 3-pole
ZCT324	AE2000-SW ~ AE3200-SW 4-pole

ZCT for transformer ground wire


ZCT15B	ZCT30B	ZCT40B	ZCT60B	ZCT80B	ZCT100B
--------	--------	--------	--------	--------	---------

As for outline dimensions refer to page 50. Make choice of suitable ZCT in conformity to the BUSBAR size.


ER function block diagram (for load circuit method)



ER function block diagram (transformer ground wire method)



Earth leakage protection characteristics



Accessories

2nd Additional Pre-alarm (AP)


Option



The Pre-Alarm (1st) function already installed in standard breaker, the 2nd additional Pre-Alarm function can be installed as option, thereby it is possible to monitor (observer) electric circuit in more detail by 2nd additional Pre-Alarm function.

Setting item	Mark	Adjustable setting range	Accuracy	Factory default value
2nd Additional Pre-alarm pick-up current	Ip2	0.5-0.6-0.7-0.8-0.84-0.88-0.92-0.96-1.0 x Iu <input type="text" value="WS"/>	±10% <input type="text" value="WS"/>	1.0
		0.5-0.6-0.7-0.8-0.84-0.88-0.92-0.96-1.0 x Iu <input type="text" value="WM"/>	±5% <input type="text" value="WM"/>	
2nd Additional Pre-alarm time	Tp2	$\frac{0.9-0.8-0.7-0.6-0.5-0.4-0.3 \times T_L}{(x T_L)} - \frac{5-10-15-20-30-40-60s}{(FLAT)}$	±20%	0.9 (x T _L)

Pre-alarm timing chart



Neutral pole 50% protection(N5)

Option



Neutral pole overcurrent protection (operating at 100% of rated current) come already equipped with ETR as standard features.

But if you would like to operate at 50% of rated current on neutral pole, neutral pole 50% protection is available with this optional module unit.

MCR switch (MCR-SW)

Option



If MCR switch is built in the breaker and the dial for INST/MCR on Main setting module is set to the range of MCR position, MCR function is operative.

MCR function:

During a closing operation of the breaker, Instantaneous characteristics is operative.

And it becomes inoperative when the breaker is in the closed position.

Temperature alarm (TAL)

Option



If TAL sensor is built in the breaker, temperature alarm is operative. When the temperature of main contact exceeds normal level, temperature alarm is indicated by LED on main setting module and also the output contact is made energize if power supply with output contact is installed.

It is possible to know temperature rising which is caused by wear of main contact because TAL sensor is installed near main contact. When the temperature of main contact goes down to the normal level, temperature alarm turns off automatically.

Field test device (Y-2000)



The electronic trip relay can be checked by this field test device when the breaker is at test position or disconnect position. The breaker will trip when tested with this device.

Y-2000 specification

TEST ITEM	LTD,STD,INST,GFR,PAL
TEST SIGNAL RANGE	1% ~ 2500%
OUTLINE DIMENSION	230(W) x 120(H) x 290(D)
TIMER	0.000 ~ 999.999s
POWER SUPPLY	100 – 240V AC 50 / 60Hz

Electronic trip relay

Additional functions

By adding the extension module unit in ETR, additional functions like measuring, display and communication become available.


List of extension unit

Name	Type	Description
Extension module	EX1	Base module for display and interface function (indispensable)
Display module (relay attachment)	DP1	Display module for ETR
Display module (panel attachment)	DP2	Display module for panel board
VT unit	VT	Module for measuring of voltage, active power and active energy
CC-Link® interface unit	BIF-CC	Interface unit for CC-Link®
PROFIBUS-DP interface unit	BIF-PR	Interface unit for PROFIBUS-DP
MODBUS® (RS-485) interface unit	BIF-MD	Interface unit for MODBUS® (RS-485)
I/O unit	BIF-CON	Module for breaker remote control (Interface unit is required)
Drawout position switch	BIF-CL	Switch for detecting the drawout position of the breaker (Interface unit and I/O unit are required.)


Selection samples of additional function modules

(○:required optional modules)

Additional function		Name	Extension module	Display	VT unit	Interface unit		
		Type	EX1	DP1 or/and DP2	VT	BIF-CC	BIF-PR	BIF-MD
Load current	Display		○	○				
		Communication	○			○		
			○				○	
	Display & Communication	CC-Link®	○	○		○		
		PROFIBUS-DP	○	○			○	
		MODBUS®	○	○				○
Voltage Power Energy Harmonics current etc.	Display		○	○	○			
		Communication	○		○	○		
			○		○		○	
	Display & Communication	CC-Link®	○	○	○	○		
		PROFIBUS-DP	○	○	○		○	
		MODBUS®	○	○	○			○



Electronic trip relay(ETR) type code



Extension module (EX1)

Option



This is the base module that provides various additional functions with combining Display module (DP1 / DP2), Interface unit (BIF-CC / BIF-PR / BIF-MD) and VT unit (VT).

1 Various measuring elements, high measuring accuracy

By adopting high-performance ASIC, various measuring elements (load current, voltage, energy, harmonics, etc.) and high measuring accuracy are attained. Refer to page 34 for more details.

2 Communication function

2 display modules and 1 interface unit can be connected simultaneously with its advanced internal communication.

Display module (DP1/DP2)

Option



This is the module that displays and sets various information, for example, displays of measurement, trip and alarm, setting of output contacts and so on.

1 Multi display of measuring element

It enables to easily monitor the comparison of each measuring element with its multi display (4 phases multi display of load current and voltage) on one screen.

2 Two-color back light

Under trip or alarm, back light color changes from green to red automatically, which visually shows an abnormal situation.



3 Graphical display

By adopting dot matrix type LCD, graphical display such as bar graph display of load current, harmonic currents and characteristic curve is available.



There are 2 types of display module. One is the ETR attachment type (DP1). Another is the panel attachment type (DP2), which can be connected to extension terminals of control circuit with 2m cable. 2 units of display modules (DP1 and DP2) can be attached on one breaker. (As for outline dimensions of DP2, refer to page 51.)

Note;

- Extension module (EX1) is required.
- VT unit (VT) is required to display the measured data except load current.

VT unit (VT)

Option



VT unit enables to measure voltages, powers, energies, harmonic currents and etc. by connecting the ETR with Extension module (EX1). (outline dimensions are shown in page 52.)

Note;

- The length of the cable attached for VT unit is 2m.

Electronic trip relay

Network

Interface unit (BIF-CC/BIF-PR/BIF-MD)

Option



BIF-CC (CC-Link®)



BIF-PR (PROFIBUS-DP)



BIF-MD (MODBUS®(RS-485))


These Interface units can expand the future possibility in various communication and Intelligent control.

1 Applicable to various open networks.

These units are applicable to various open network systems such as CC-Link®, PROFIBUS-DP and MODBUS® (RS-485), which can be built in easily.

2 Intelligent control by Multi-data communication

It comes into being the Intelligent control by Multi-data communication through these interface units to PLC/SCADA, which transfer the measurement Information, setting values, error information and trip and alarm informations.



The length of the cable for interface unit is 2m.

Note: Some device types are excluded.

Note:

- Extension module (EX1) is required.
- VT unit (VT) is required to transmit the measured data except load current.

I/O unit (BIF-CON)

Option




BIF-CON

The Input & Output Controlling Unit (BIF-CON) is available for the remote controlling and remote monitoring of the breaker condition through the various network systems. With this BIF-CON unit in addition to the Interface Unit, it become possible to control the breaker remotely, like a ON or OFF operations or Spring-charging.

Function	Description	Note
Control	Breaker ON operation	1a contact for Closing coil (CC)
	Breaker OFF operation	1a contact for Shunt trip device (SHT) (not applicable for AC380-500V rating)
	Spring charge	1a contact for Motor charging (MD)
Monitor	Digital Input (DI) monitoring	For BIF-CC and BIF-MD, Max. 3 contacts monitoring are available. For BIF-PR, 1 contact monitoring is available.

Drawout position switch (BIF-CL)

Option





BIF-CL

With this Drawout position switch (BIF-CL) in addition to Interface unit and I/O unit (BIF-CON), the remote monitoring of draw-out position become available in case of the breaker draw-out type.

Function	Description	Note
Monitor	Breaker Drawout position	Position : Connect or Test or Disconnect


○ : can be displayed by DP1/DP2

● : can be displayed and set by DP1/DP2

Combination sample																								
Type	<div>①② - ③ ;EX1;DP1(;;DP2)^{Note 1)}</div>												<div>①② - ③ ;EX1;DP1(;;DP2),VT^{Note 1)}</div>											
①Main setting module	WS				WM				WB				WS				WM				WB			
②Optional setting module	NA	AP	G1	E1	NA	AP	G1	E1	NA	AP	G1	E1	NA	AP	G1	E1	NA	AP	G1	E1	NA	AP	G1	E1
③Power supply	P1~P5												P1~P5											
Measurement																								
Load current (±2.5%)	○												○											
Leakage current (±15%) ^{Note 4)}	-	-	-	○	-	-	-	○	-	-	-	○	-	-	-	○	-	-	-	○	-	-	-	○
Voltage (±2.5%)	-												○											
Power (active,reactive,apparent) (±2.5%)	-												○											
Power factor (±5%)	-												○											
Energy (active,reactive) (±2.5%)	-												○											
Harmonics current (±2.5%)	-												○ (3.5...19th)											
Frequency (±2.5%)	-												○											
Trip history																								
LTD	○				○				-				○				○				-			
STD	○				○				-				○				○				-			
INST	○												○											
GFR	-	-	○	-	-	-	○	-	-	-	○	-	-	-	○	-	-	-	○	-	-	-	○	-
ER	-	-	-	○	-	-	-	○	-	-	-	○	-	-	-	○	-	-	-	○	-	-	-	○
UVT	○ ^{Note 2)}												○ ^{Note 2)}											
Alarm history																								
PAL1	○												○											
PAL2	-	○	-	-	-	○	-	-	-	○	-	-	-	○	-	-	-	○	-	-	-	○	-	-
OVER	○												○											
GFR	-	-	○	-	-	-	○	-	-	-	○	-	-	-	○	-	-	-	○	-	-	-	○	-
EPAL	-	-	-	○	-	-	-	○	-	-	-	○	-	-	-	○	-	-	-	○	-	-	-	○
ER	-	-	-	○	-	-	-	○	-	-	-	○	-	-	-	○	-	-	-	○	-	-	-	○
TAL	○ ^{Note 3)}												○ ^{Note 3)}											
Characteristic setting (panel attachment product [DP2] only)																								
LTD	○				○				-				○				○				-			
STD	○				○				-				○				○				-			
INST	○												○											
PAL1	○												○											
PAL2	-	○	-	-	-	○	-	-	-	○	-	-	-	○	-	-	-	○	-	-	-	○	-	-
GFR	-	-	○	-	-	-	○	-	-	-	○	-	-	-	○	-	-	-	○	-	-	-	○	-
EPAL	-	-	-	●	-	-	-	●	-	-	-	●	-	-	-	●	-	-	-	●	-	-	-	●
ER	-	-	-	○	-	-	-	○	-	-	-	○	-	-	-	○	-	-	-	○	-	-	-	○
Setting																								
Contact outputs setting change	●												●											
Date & Time	●												●											
Demand time	●												●											
Alarm holding method	●												●											
Reset																								
Trip and alarm information	●												●											
Measurement information (min. and max. values)	●												●											
ETR information																								
Main / Optional setting module information	○												○											
Error information	○												○											
CT rating (In)	○												○											
Phase line method	○												○											
Normal connection or reverse connection	○												○											

Electronic trip relay

Electronic trip relay circuit diagram



① Power supply CT

Energy is supplied for the operation of the overcurrent tripping and ground fault tripping(GFR) function of the electronic trip relay.

② Current sensor coil

The current in each phase flowing through in the breaker is detected. A air core coil which has good linearity is achieved.

③ Power supply circuit

This part convert power supply CT energy to constant voltage for respective circuits in the ETR.

④ ASIC

This amplifies signal detected by the current sensor coil, and detects ground fault current by vector composition.

⑤ Microprocessor

The microprocessor integrates each phase current waveforms from the ASIC and performs processing for overcurrent protection and others.

⑥ Characteristic setting module

The module for the characteristic setting of the ETR.

⑦ Several LEDs

The load current LED give a figure of current in percent by CT energy.

Trip indicator and pre-alarm are indicated by control power supply.

RUN and ERR. LED indicate breaker's condition by control power supply or ten-odd percent of CT energy.


⑧ Power supply with contact output

This outputs contact signal at fault cause (including pre-alarm) and at other alarms.


A control supply is necessary for this function.

Setting procedure

Press the screwdriver in the direction of the arrow to open the cover




- 1 Prepare a small flat tipped screwdriver.



- 2 Insert the flat tipped screwdriver into the opening of the ETR cover. Then, lightly turn the screwdriver to the upside as shown in the left figure, and the ETR cover will open.

- 3 There are two kinds of switches for characteristics setting and for trip indicator reset. They should be used as follows.



- ① Adjustable in steps
- ② Push-button

- ① Adjustable in steps

Rotary code switch is used. Do not set the switch at points between steps. The setting value is same when the switch is positioned at the thick line. (Set the switch with a torque of 0.02N·m or below.)

- ② Push-button

This is for temporary operation, and press it with force of 3N or less.

- 4 When the characteristic is set up, use a device like a field tester, etc to make sure that the required characteristic has been set.

- 5 At sealing, seal the ETR cover by using the sealing hole at the top of the ETR cover.

